


Owner's Manual

Standard or Deluxe Control Box for: 6002 * 6003 * 6400 Vehicular Swing Gate Operators





CONTROL BOXES SPECIFICATIONS

Class of Operation	Models 6002, 6003 and 6400 - UL325 Class I
Type of Gate	Residential Vehicular Swing Gates Only
Voltage / Phase	115 VAC 60 Hz Single Phase Input Power – 24 VDC Operating Power
Back-Up Power	24 VDC battery power during power outages.


Standard Control Box

P/N 4302-111




Deluxe Control Box

P/N 4302-112



115 VAC convenience outlets to power auxiliary power transformers.




DoorKing, Inc. reserves the right to make changes in the products described in this manual without notice and without obligation of DoorKing, Inc. to notify any persons of any such revisions or changes. Additionally, DoorKing, Inc. makes no representations or warranties with respect to this manual. This manual is copyrighted, all rights reserved. No portion of this manual may be copied, reproduced, translated, or reduced to any electronic medium without prior written consent from DoorKing, Inc.

6002 and 6003 SPECIFICATIONS

6002


Class of Operation	Model 6002 - UL325 Class I
Type of Gate	Residential Vehicular Swing Gates Only
Motor RPM	1400
Maximum Thrust	300 daN
Voltage / Phase	115 VAC Single Phase Input Power – 24 VDC Operating Power
Current	3 Amps
Max Gate Weight	500 Lbs.
Max Gate Length	14 Feet
Useful Rod Stroke	14 inches
Cycles Per Hour	10 Per Hour with AC connected
Speed	90° in approximately 15 seconds
Entrapment Protection	Primary - Inherent entrapment sensing system (Type A) Secondary - Provision for connection of a non-contact sensor (Type B1)



Drawings not to scale

6003

Class of Operation	Model 6003 - UL325 Class I
Type of Gate	Residential Vehicular Swing Gates Only
Motor RPM	1400
Maximum Thrust	300 daN
Voltage / Phase	115 VAC Single Phase Input Power – 24 VDC Operating Power
Current	3 Amps
Max Gate Weight	300 Lbs.
Max Gate Length	10 Feet.
Useful Rod Stroke	14 inches
Cycles Per Hour	10 Per Hour with AC connected
Speed	90° in approximately 15 seconds
Entrapment Protection	Primary - Inherent entrapment sensing system (Type A) Secondary - Provision for connection of a non-contact sensor (Type B1)



6400 SPECIFICATIONS

Class of Operation	Model 6400 - UL325 Class I
Type of Gate	Residential Vehicular Swing Gates Only
Motor Torque	300 Nm
Voltage / Phase	115 VAC Single Phase Input Power – 24 VDC Operating Power
Current	3 Amps
Max Gate Weight	300 Lbs.
Max Gate Length	10 Feet
Cycles Per Hour	20 Per Hour with AC connected
Speed	90° in approximately 20 seconds
Entrapment Protection	Primary - Inherent entrapment sensing system (Type A) Secondary - Provision for connection of a non-contact sensor (Type B1)

Underground Operator




TABLE OF CONTENTS

SPECIFICATIONS

Control Box, Standard and Deluxe Specifications	1
6002 Specifications	2
6003 Specifications	2
6400 Specifications	3

SAFETY

Gate Construction	6
Important Safety Instructions	6
Instructions regarding intended installation:	6-7
Important Notices	7
UL325 Entrapment Protection	8
Glossary	9
Swing Gate Requirements	10
Swing Gate Protection	11

SECTION 1 - INSTALLATION OVERVIEW 12

Installation of 6002 Actuator Arm 13-16

- Removing 6002 Actuator Cover
- 6002 Manual Release
- Cover the Holes on Top
- 6002 "Opening to the Inside"
- 6002 "Opening to the Outside"
- Mounting 6002 Actuator Arm




Installation of 6003 Actuator Arm 17-19

- 6003 Manual Key Release
- 6003 "Opening to the Outside"
- 6003 "Opening to the Inside"
- Mounting 6003 Actuator Arm




Installation of 6400 Underground Operator 20-22

- 6400 Single Hinge Setup
- 6400 Two Hinge Setup
- 6400 Gate Opening Direction
- 6400 Dual Gates Opening in Either Direction



SECTION 2 - INSTALL CONTROL BOX 23

2.1 Install Control Box 23



2.2 Installation of Warning Signs 23

SECTION 3 - WIRING 24

3.1 Wiring Operator(s) 24

3.2 Secondary Entrapment Protection Wiring 25

3.3 Main Terminal Description 26

3.4 Main Terminal Wiring 27

3.5 Loop Detector Wiring 28

3.6 High Voltage Wiring and Battery Connection 29

SECTION 4 - ADJUSTMENTS 30

4.1 Circuit Board Adjustments 30

4.2 DIP-Switch Settings 31-32

4.3 Limit Sensor Adjustments 32

4.4 Inherent Entrapment Sensing Adjustment 32-33

4.5 Shutdown Conditions 33-34

Soft Shutdown and Resetting
Hard Shutdown and Resetting

SECTION 5 - MAINTENANCE AND TROUBLESHOOTING 35

5.1 Maintenance 35

5.2 Diagnostics Check 35-36

5.3 Troubleshooting 36-37

5.4 Accessory Items 37

Control Box, Deluxe or Standard Wiring Diagram 38

Model 6002, 6003 and 6400's Wiring Diagrams 39

Gate Construction

Vehicular gates should be constructed and installed in accordance with ASTM F2200; Standard Specification for Automated Vehicular Gate Construction. For a copy of this standard, contact ASTM directly at 610-832-9585; service@astm.org; or www.astm.org.

Important Safety Instructions

WARNING - To reduce the risk of injury or death:

1. READ AND FOLLOW ALL INSTRUCTIONS.
2. Never let children operate or play with gate controls. Keep the remote control away from children.
3. Always keep people and objects away from gate. **NO ONE SHOULD CROSS THE PATH OF THE MOVING GATE.**
4. Test the operator monthly. The gate MUST reverse on contact with a rigid object or stop or reverse when an object activates the non-contact sensors. After adjusting the force or the limit of travel, retest the gate operator. Failure to adjust and retest the gate operator properly can increase the risk of injury or death.
5. Use the emergency release only when the gate is not moving.
6. KEEP GATES PROPERLY MAINTAINED. Read the owner's manual. Have a qualified service person make repairs to gate hardware.
7. The entrance is for vehicles only. Pedestrians must use separate entrance.
8. **SAVE THESE INSTRUCTIONS!**

Instructions regarding intended installation:

- Install the gate operator only if:
 1. The operator is appropriate for the construction of the gate and the usage class of the gate.
 2. All openings of a horizontal slide gate are guarded or screened from the bottom of the gate to a minimum of 4 feet (1.22 m) above the ground to prevent a 2 ¼ inch (57.2 mm) diameter sphere from passing through the openings anywhere in the gate, and in that portion of the adjacent fence that the gate covers in the open position.
 3. All exposed pinch points are eliminated or guarded.
 4. Guarding is supplied for exposed rollers.
- The operator is intended for installation only on gates used for vehicles. Pedestrians must be supplied with a separate access opening. The pedestrian access opening shall be designed to promote pedestrian usage. Locate the gate such that persons will not come in contact with the vehicular gate during the entire path of travel of the vehicular gate.
- The gate must be installed in a location so that enough clearance is supplied between the gate and adjacent structures when opening and closing to reduce the risk of entrapment. Swinging gates should not open into public access areas.
- The gate must be properly installed and work freely in both directions prior to the installation of the gate operator. Do not over-tighten the operator clutch, pressure relief valve or reduce reversing sensitivity to compensate for a damaged gate.
- For gate operators utilizing Type D protection:
 1. The gate operator controls must be placed so that the user has full view of the gate area when the gate is moving.
 2. A warning placard shall be placed adjacent to the controls.
 3. An automatic closing device (such as a timer, loop sensor, or similar device) shall not be employed.
 4. No other activation device shall be connected.
- Controls intended for user activation must be located at least ten feet (10') away from any moving part of the gate and where the user is prevented from reaching over, under, around or through the gate to operate the controls. Outdoor or easily accessible controls should have a security feature to prevent unauthorized use.
- The Stop and/or Reset button must be located in the line-of-sight of the gate. Activation of the reset control shall not cause the operator to start.
- A minimum of two (2) WARNING SIGNS shall be installed, one on each side of the gate where easily visible.
- For gate operators utilizing a non-contact sensor:
 1. See the instructions on the placement of non-contact sensors for each type of application.
 2. Care shall be exercised to reduce the risk of nuisance tripping, such as when a vehicle trips the sensor while the gate is still moving in the opening direction.
 3. One or more non-contact sensors shall be located where the risk of entrapment or obstruction exist, such as the perimeter reachable by a moving gate or barrier.

- For gate operators utilizing contact sensors:
 1. One or more contact sensors shall be located where the risk of entrapment or obstruction exist, such as at the leading edge, trailing edge, and post mounted both inside and outside of a vehicular horizontal slide gate.
 2. One or more contact sensors shall be located at the bottom edge of a vehicular vertical lift gate.
 3. One or more contact sensors shall be located at the pinch point of a vehicular vertical pivot gate.
 4. A hardwired contact sensor shall be located and its wiring arranged so that the communication between the sensor and the gate operator is not subjected to mechanical damage.
 5. A wireless contact sensor such as one that transmits radio frequency (RF) signals to the gate operator for entrapment protection functions shall be located where the transmission of the signals are not obstructed or impeded by building structures, natural landscaping or similar obstructions. A wireless contact sensor shall function under the intended end-use conditions.
 6. One or more contact sensors shall be located at the bottom edge of a vertical barrier (arm).

Important Notices

Vehicular gate operator products provide convenience and security. However, gate operators must use high levels of force to move gates and most people underestimate the power of these systems and do not realize the potential hazards associated with an incorrectly designed or installed system. These hazards may include:

- Pinch points
- Entrapment areas
- Reach through hazards
- Absence of entrapment protection devices
- Improperly located access controls
- Absence of vehicle protection devices
- Absence of controlled pedestrian access

In addition to these potential hazards, automated vehicular gate systems must be installed in accordance with the UL-325 Safety Standard and the ASTM F2200 Construction Standard. Most lay persons are unaware of, or are not familiar with, these standards. If an automated vehicular gate system is not properly designed, installed, used and maintained, serious injuries or death can result. Be sure that the installer has instructed you on the proper operation of the gate and gate operator system.

Be sure that the installer has trained you about the basic functions of the required reversing systems associated with your gate operating system and how to test them. These include reversing loops, inherent reversing system, electric edges, photoelectric cells, or other external devices.


- This Owner's Manual is your property. Keep it in a safe place for future reference.
- Be sure that all access control devices are installed a minimum distance of 10 feet away from the gate and gate operator, or in such a way that a person cannot touch the gate or gate operator while using the device. If access control devices are installed in violation of these restrictions, immediately remove the gate operator from service and contact your installing dealer.
- Loops and loop detectors, photo-cells or other equivalent devices must be installed to prevent the gate from closing on vehicular traffic.
- The speed limit for vehicular traffic through the gate area is 5 MPH. Install speed bumps and signs to keep vehicular traffic from speeding through the gate area. Failure to adhere to posted speed limits can result in damage to the gate, gate operator, and to the vehicle.
- Be sure that all persons who will use the gate system are familiar with the proper use of the gate and gate operator and are familiar with the possible hazards associated with the gate system.
- Be sure that warning signs are permanently installed on both sides of the gate in an area where they are fully visible to traffic.
- It is your responsibility to periodically check all entrapment protection devices. If any of these devices are observed to function improperly, remove the operator from service immediately and contact your installing or servicing dealer.
- Follow the recommended maintenance schedule.
- Do not allow children to play in the area of the operator or to play with any gate-operating device.
- To remove the gate operator from service, operate the gate to the full open position and then shut off power to the operator at the service panel.

UL325 Entrapment Protection



Class I

A vehicular gate operator (or system) intended for use in a home of one-to four single family dwelling, or a garage or parking area associated therewith.



Class II

A vehicular gate operator (or system) intended for use in a commercial location or building such as a multi-family housing unit (five or more single family units) hotel, garages, retail store or other building servicing the general public.



Class III

A vehicular gate operator (or system) intended for use in an industrial location or building such as a factory or loading dock area or other locations not intended to service the general public.



Class IV

A vehicular gate operator (or system) intended for use in a guarded industrial location or building such as an airport security area or other restricted access locations not servicing the general public, in which unauthorized access is prevented via supervision by security personnel.

This table illustrates the entrapment protection requirements for each of the four UL325 classes.

UL325 Classifications	Horizontal Slide, Vertical Lift, Vertical Pivot		Swing and Vertical Barrier (arm)	
	Primary Protection	Secondary Protection	Primary Protection	Secondary Protection
Class I and II	A	B1, B2 or D	A or C	A, B1, B2, C or D
Class III	A, B1 or B2	A, B1, B2, D or E	A, B1, B2 or C	A, B1, B2, C or D
Class IV	A, B1, B2 or D	A, B1, B2, D or E	A, B1, B2, C or D	A, B1, B2, C, D or E

- A - Inherent entrapment protection system.
- B1 - Provision for connection of, or supplied with, a non-contact sensor (photoelectric sensor or the equivalent). When used as the PRIMARY device, must be monitored.
- B2 - Provision for connection of, or supplied with, a contact sensor (edge device or the equivalent). When used as the PRIMARY device, must be monitored.
- C - Inherent adjustable clutch or pressure relief device.
- D - Provision for connection of, or supplied with, an actuating device requiring continuous pressure to maintain opening or closing motion of the gate.
- E - An inherent audio alarm.

Glossary

GATE - A moving barrier such as a swinging, sliding, raising, lowering, or the like, barrier, that is a stand-alone passage barrier or is that portion of a wall or fence system that controls entrance and/or egress by persons or vehicles and completes the perimeter of a defined area.

RESIDENTIAL VEHICULAR GATE OPERATOR – CLASS I - A vehicular gate operator (or system) intended for use in a home of one-to four single family dwelling, or garage or parking area associated therewith.

COMMERCIAL / GENERAL ACCESS VEHICULAR GATE OPERATOR - CLASS II - A vehicular gate operator (or system) intended for use in a commercial location or building such as a multi-family housing unit (five or more single family units), hotels, garages, retail store, or other building servicing the general public.

INDUSTRIAL / LIMITED ACCESS VEHICULAR GATE OPERATOR - CLASS III - A vehicular gate operator (or system) intended for use in an industrial location or building such as a factory or loading dock area or other locations not intended to service the general public.

RESTRICTED ACCESS VEHICULAR GATE OPERATOR - CLASS IV - A vehicular gate operator (or system) intended for use in a guarded industrial location or building such as an airport security area or other restricted access locations not servicing the general public, in which unauthorized access is prevented via supervision by security personnel.

VEHICULAR BARRIER (ARM) OPERATOR (OR SYSTEM) - An operator (or system) that controls a cantilever type device (or system), consisting of a mechanical arm or barrier that moves in a vertical arc, intended for vehicular traffic flow at entrances or exits to areas such as parking garages, lots or toll areas.

VEHICULAR HORIZONTAL SLIDE-GATE OPERATOR (OR SYSTEM) - A vehicular gate operator (or system) that controls a gate which slides in a horizontal direction that is intended for use for vehicular entrance and exit to a drive, parking lot, or the like.

VEHICULAR SWING-GATE OPERATOR (OR SYSTEM) - A vehicular gate operator (or system) that controls a gate which moves in an arc in a horizontal plane that is intended for use for vehicular entrance and exit to a drive, parking lot, or the like.

SYSTEM - In the context of these requirements, a system refers to a group of interacting devices intended to perform a common function.

WIRED CONTROL - A control implemented in a form of fixed physical interconnections between the control, the associated devices, and an operator to perform predetermined functions in response to input signals.

WIRELESS CONTROL - A control implemented in means other than fixed physical interconnections (such as radio waves or infrared beams) between the control, the associated devices, and an operator to perform predetermined functions in response to input signals.




INHERENT ENTRAPMENT PROTECTION SYSTEM - A system, examples being a motor current or speed sensing system, which provides protection against entrapment upon sensing an object and is incorporated as a permanent and integral part of the operator.

EXTERNAL ENTRAPMENT PROTECTION DEVICE - A device, examples being an edge sensor, a photoelectric sensor, or similar entrapment protection device, which provides protection against entrapment when activated and is not incorporated as a permanent part of an operator.

ENTRAPMENT - The condition when an object is caught or held in a position that increases the risk of injury.


Swing Gate Requirements

The operator is intended for installation only on gates used for vehicles. Pedestrians must be supplied with a separate access opening. The pedestrian access opening shall be designed to promote pedestrian usage. Locate the gate such that persons will not come in contact with the vehicular gate during the entire path of travel of the vehicular gate. (ref. UL325 56.8.4.b)



Gates shall have smooth bottom edges, with vertical bottom edged protrusions not exceeding 0.50 inches. ASTM F2200 4.3

Swing Gate Protection



SECTION 1 - INSTALLATION OVERVIEW

Prior to beginning the installation of your swing gate operator, we suggest that you become familiar with the specific instructions, illustrations, and wiring guide-lines for your specific operator in this manual. This will help insure that your installation is performed in an efficient and professional manner.

The proper installation of a vehicular swing gate operator is an extremely important and integral part of the overall access control system. Check all local building ordinances and building codes prior to installing your operator. Be sure your installation is in compliance with local codes.

Important: Consider hinge placement on a pilaster when installing the gate. Placing hinges close to the edge of the pilaster can eliminate a potential entrapment area (See Swing Gate Requirements on page 10).

Installing 6002 Actuator Arm Pages 13 through 16


Installation instructions for the 6002 actuator arm **ONLY**. After 6002 arm has been installed, continue to Section 2 for control box installation.

Installing 6003 Actuator Arm Pages 17 through 19


Installation instructions for the 6003 actuator arm **ONLY**. After 6003 arm has been installed, continue to Section 2 for control box installation.

Installing 6400 Underground Operator Pages 20 through 22

Installation instructions for the 6400 underground operator **ONLY**. After 6400 has been installed, continue to Section 2 for control box installation.




Removing 6002 Actuator Cover



6002 Manual Release


The actuator arm can be manually operated in case of power failure. Never manually release the arm until you have verified that ALL power has been shut-off to it (Including batteries).




Cover Holes on Top

Cover the exposed holes on top of the 6002 arm with the aluminum tape.

Do not cover the holes on the bottom of 6002 arm.




6002 "Opening to the Inside"



! Do not install the actuator in fully extended (Bottomed out) position. This will damage the arm. See page 16 to prevent this from happening.


Mechanically Attaching Brackets to Surfaces

When mounting brackets with bolts to the wall and/or gate, weld reinforcing steel plates to the brackets. Completely weld around brackets. The brackets must be perpendicular to the wall and/or gate and horizontally level.




! Support Bar

A support bar must span the entire length of the gate to support the gate pickets. The pickets will bend if not supported.




Actuator arm and brackets **MUST** be level!




6002 "Opening to the Outside"

Mechanically Attaching Brackets to Surfaces

When mounting brackets with bolts to the wall and/or gate, weld reinforcing steel plates to the brackets. Completely weld around brackets. The brackets must be perpendicular to the wall and/or gate and horizontally level.




⚠ Do not install the actuator in fully extended (Bottomed out) position. This will damage the arm. See next page to prevent this from happening.



⚠ Support Bar

A support bar must span the entire length of the gate to support the gate pickets. The pickets will bend if not supported.



Mounting 6002 Actuator Arm


Gate must be in good working condition before the actuator arm can be installed. Determine what direction the actuator arm will open the gate "Opening to the Inside" or "Opening to the Outside" (See 2 previous pages).

Gate Support Bar

A support bar that spans the entire length of the gate must be installed to keep the pickets from bending. **Do not mount the front bracket directly to gate pickets!**



Prevent Powered Shaft Bottoming Out

It is very important that the powered shaft is not fully extended when installed on the gate (bottoming out). This will damage the arm. To prevent this, manually release the arm and fully extend the powered shaft. Rotate it back two full turns before installing the arm.



Clevis Pins

Note: Front clevis pin **MUST** fit into countersunk hole to allow retaining ring to be installed.




Bracket Fabrication


The brackets need to be fabricated before the arm can be installed. Brackets will vary in size depending on the opening direction of the gate and the thickness of the wall the actuator arm will attach to. They can be attached to the wall and gate by welding and/or mechanically, depending on the type wall and gate. **The brackets must be perpendicular to the wall and/or gate and horizontally level. Make sure the brackets will be VERY secure when fastened to the wall and gate.**

Welding Brackets to Surfaces

If brackets are going to be welded to the gate and/or wall, **only tack weld the brackets with the arm attached. Protect the arm from welding sparks during tack welding. Remove arm before completely welding around the brackets. Make sure the brackets are level when tack welding them!** The arm will not operate properly if not level.




6003 Manual Key Release




Manually key release the actuator. Powered shaft can be pulled out.

6003 "Opening to the Inside"



Attaching Brackets

The brackets must be **securely** mounted and **level**.




6003 "Opening to the Outside"

Attaching Brackets

The brackets must be **securely** mounted and **level**.

Front Bracket

Bolt to support bar.




Rear Bracket

Bolt support bracket to fabricated steel plate with supplied lock nuts.

Rear Bracket Fabrication

A rear bracket will need to be fabricated. The bracket will vary in size depending on the gate hinge inset. It can be attached to the wall by welding or bolting, depending on the type wall. **The bracket MUST be level and VERY secure to the wall. Extreme force will be exerted on this bracket during gate cycling.**



⚠ Do not install the actuator in fully extended (Bottomed out) position. This will damage the arm. See next page to prevent this from happening.

⚠ Support Bar

A support bar must span the entire length of the gate to support the gate pickets. The pickets will bend if not supported.



Mounting 6003 Actuator Arm


Gate must be in good working condition before the 6003 actuator arm can be installed. Determine what direction the actuator arm will open the gate: "Opening to the Outside" or "Opening to the Inside"(See 2 previous pages).

Gate Support Bar

A support bar that spans the entire length of the gate must be installed to keep the pickets from bending. **Do not mount the front bracket directly to gate pickets!**


Prevent Powered Shaft Bottoming Out

It is very important that the powered shaft is not fully extended when installed on the gate (bottoming out). This will damage the arm. **To prevent this, manually release the arm and fully extend the powered shaft. Rotate it back two full turns before installing the arm.**



Rear Bracket Configurations for Different Gate Hinge Insets

This illustrates when the gate is "Opening to the Inside" Only. Gate Hinge Pivot Point



Welding Brackets to Surfaces


If brackets are going to be welded to the gate and/or wall, **only tack weld the brackets with the arm attached. Protect the arm from welding sparks during tack welding. Remove arm before completely welding around the brackets. Make sure the brackets are level when tack welding them!** The arm will not operate properly if not level.

After the 6003 actuator arm has been mounted to the gate, proceed to page 23 to install the control box.


6400 Single Hinge Setup

The gate weight will be on the foundation box of the 6400. It is recommended that the concrete is reinforced around the foundation box to handle the weight of the gate (300 lbs max.). It is preferred that a heavy gate be supported by two hinges instead of the foundation box (See next page).

The foundation box **MUST** have a drain pipe installed with the correct slope for proper drainage. Improper drainage of the foundation box will result in stagnant water that will eventually lead to operator failure.




The depth of the concrete is determined by specific installation requirements, soil conditions and local building codes.



Foundation box **MUST** be level and flush with driveway surface.


Important: Remove all parts from inside of foundation box before mounting into concrete.

Single Hinge Gate Connection



Manual Release


Unlock and pull release handle to manually operate the gate.



After the foundation box has been mounted and the gate has been connected to it, proceed to page 22 to install components in the box.

6400 Two Hinge Setup


The gate weight is supported by the gate hinges and **NOT** on the foundation box. This is preferred for heavy gates. The foundation box **MUST** have a drain pipe installed with the correct slope for proper drainage. Improper drainage of the foundation box will result in stagnant water that will lead to operator failure eventually.



The depth of the concrete is determined by specific installation requirements, soil conditions and local building codes.


Important: Remove all parts from inside of foundation box before mounting into concrete.

Two Hinge Gate Connection



6400 Gate Opening Direction

The drive motor orientation determines the opening direction of the gate. It can be unbolted and flipped 180° to allow the gate to open in either direction. See setups below for your specific opening direction. **Factory setup opens gate counter-clockwise.**




Limit sensors are factory set in the "Open counter-clockwise" position.

Limit sensors must be slid 90° clockwise on limit plate to be in the correct "Open clockwise" position.

Note: Final limit adjustments will be made after AC power has been connected.

6400 Dual Gates Opening in Either Direction

The **secondary** operator motor wires must be reversed if dual operators are used (Blue wire to #1 and Brown wire to #2). See page 24 for more information.



Drive motors face the same direction in a dual gate installation. Limit sensors are positioned according to the opening direction of the gate (See limit plates shown above).


SECTION 2 - INSTALL CONTROL BOX

Permanent wiring must be installed to the operator as required by local electrical codes. It is recommended that a licensed electrical contractor perform this work. Check local building codes prior to installing any permanent wiring to ensure all wiring and connections comply with local electrical code requirements..

2.1 Install Control Box

Position the control box on the wall, close enough to the operator so the primary operator cable can be easily routed inside the box. Secure the control box to the wall with appropriate hardware (not included). Control box has predrilled mounting holes. All power and control wires should be routed to control box in conduits with sweeps. Never run high voltage and low voltage wires in the same conduit, keep them in separate conduits.

- 3/4" conduit recommended. Use only sweeps for conduit bends and **NOT** elbow connectors. Elbows will make wire pulls very difficult and can cause damage to wire insulation.
- Remove fragile components from control box to protect them during installation if necessary.



2.2 Installation of Warning Signs

This DoorKing Swing Gate Operator is shipped with two warning signs. The purpose of the warning sign is to alert uninformed persons, and to remind persons familiar with the gate system, that a possible hazard exists so that appropriate action can be taken to avoid the hazard or to reduce exposure to the hazard.

- **Permanently install the supplied warning signs in locations so that the signs are visible by persons on both sides of the gate.**
- Use appropriate hardware such as wood or sheet metal screws (not supplied) to install the warning signs.



SECTION 3 - WIRING


Before attempting to connect any wiring to the control box, be sure that the circuit breaker in the electrical panel is in the OFF position. Permanent wiring must be installed to the control box as required by local electrical codes. It is recommended that a licensed electrical contractor perform this work.

Since building codes vary from city to city, we highly recommend that you check with your local building department prior to installing any permanent wiring to be sure that all wiring to the control box (both high and low voltage) complies with local code requirements.


GATE OPERATOR(S) MUST BE PROPERLY GROUNDED!!

3.1 Wiring Operator(s)



Primary or Secondary Wiring



6400 Secondary Wiring ONLY!





Motor wires **MUST** be reversed for the **6400 Secondary** operator **ONLY**.




3.2 Secondary Entrapment Protection Wiring

In addition to the inherent reversing sensor system, this operator has provisions for the connection of a non-contact (type B1) secondary entrapment protection device. This is required by UL 325 standards. DoorKing highly recommends installing loops and loop detectors to enhance this secondary entrapment protection.

Entrapment protection devices are required to reduce the risk of injury. Install sensors where the risk of entrapment or obstruction exists while gate is moving.




3.3 Main Terminal Description



3.4 Main Terminal Wiring

Controls must be far enough from the gate so that the user is prevented from coming in contact with the gate while operating the controls. Outdoor or easily accessible controls should have a security feature to prevent unauthorized use. When installing electrical equipment make certain all wiring complies with local code requirements. Do not power any control devices from the circuit board other than low voltage devices.



3.5 Loop Detector Wiring

To protect the operator from accidentally closing on vehicles in the gate's path, DoorKing highly recommends that loops and loop detectors be installed. Loops are laid underneath, cut into asphalt or concrete driveways or buried beneath gravel and earth driveways. A loop detection system will sense a vehicle like a metal detector and send a signal to the gate operator preventing the gate from automatically opening or closing on a vehicle when it is in the gate's swing path. Refer to the separate loop and loop detectors information manual (Located at DoorKing's web site) for further information. DoorKing recommends that a licensed installer perform this work.

Shadow Loop

The shadow loop is placed inside the gate's swinging path to prevent the gate from closing on a vehicle in this area. **It is only active when the gate is in the full open position.** Vehicles in the shadow area will activate it. It will not allow the gate to close unless this area is clear. After a closing cycle begins, the shadow loop **will not** reverse the gate. Reverse loops work in conjunction with the shadow loop and both should be used.


Reverse Loops

Reverse loops are placed just outside the gate's swinging path to prevent the gate from closing on a vehicle in these areas. They will stop or reverse the cycling of the gate while a vehicle is in or near the gate's swing pathway. Reverse loops are wired in series.

Automatic Exit Loop

Automatically opens the gate for exiting vehicles without having to use a transmitter or keypad. The exit loop can be placed 20-100 feet away from the gate so that the gate is open or partially open as you drive up to it.

Note: Loop detector wiring is shown for DoorKing plug-in loop detectors P/N 9409-010 and P/N 9410-010 only. If other loop detectors are used, refer to the installation instructions supplied with those detectors for wiring instructions.



Shadow Loop Output


- Shadow Loop DIP-Switch Settings**
- SW 1**

1	ON
2	ON
3	ON
4	ON
5	OFF
6	OFF
7	OFF
8	OFF
 - SW 2**


1	ON
2	ON
3	OFF
4	OFF

3.6 High Voltage Wiring and Battery Connection

CONTROL BOX MUST BE PROPERLY GROUNDED!!



CAUTION
Do not connect the battery to the circuit board until power is needed to test the operator.



To Cycle Operator:
After power has been connected, activate the operator by pressing the key switch button.

Important Power Note: To turn-off **ALL** power to the operator, the AC power switch must be turned off **and** the battery plug must be disconnected from the circuit board.

DANGER
HIGH VOLTAGE!

Connect 115 VAC input power wires (black and white) to black (Hot) and white (Neutral) transformer wires. Connect input green wire to chassis ground.

It is recommended that a surge suppressor be installed on the high voltage power lines.


SECTION 4 - ADJUSTMENTS

The switch settings and adjustments in this section should be made after your installation and wiring to the operator(s) is complete. **Whenever any programming or switch setting on the control board are changed, press the reset switch for new settings to take effect.**


4.1 Circuit Board Adjustments

DIP-Switches


Set DIP-switches on the circuit board to the desired setting. See switch-setting charts on next 2 pages.



Loop Detector 9410 Single Channel



Loop Detector 9409 Dual Channel



Reset Switch

RESET



Press reset switch to activate changed control board settings.

Self Test



Self Test Mode

Self test mode is for bench checks only. The operator will continually cycle the gate.



Normal Mode

The jumper must be set at normal mode to function.

Key Switch


KEY SWITCH



Cycles the operator when pressed.


Dry Relay Contact

Dry relay contacts (terminals 10-11) can be set for Normally Open (NO) or Normally Closed (NC) operation by placing the relay shorting bar on the N.O. or N.C. pins respectively.



Auto Close Timer

- Auto close timer (when turned on) SW 1, switch 4.



SW 1


Adjust from 1 second (full counter clockwise) to approximately 23 seconds (full clockwise).



1 23

Reverse Sensors



Adjust reversing sensitivity for:
PRIMARY (single) and
SECONDARY (dual) operators.
See 4.4 on pages 32 and 33.



Min Max Sensitivity

4.2 DIP-Switch Settings

Whenever any programming or switch setting on the control board is changed, press the reset switch for new settings to take effect.

SW 1 (Top 8 Switches)			
Switch	Function	Setting	Description
1	Opening Direction of Primary Operator	 OFF setting. Opens 6400 clockwise. ON setting. Opens 6400 counter-clockwise.	 OFF setting. ON setting.
2	Opening Direction of Secondary Operator		Same as primary operator above.
3	Exit loop	OFF	Terminal 4 is output from exit loop detector.
	Logic Output	ON (normal)	Terminal 4 is open command.
4	Auto-Close Timer	OFF	Auto-close timer is OFF. Manual input required to close gate.
		ON	Auto-close timer is ON. Adjustable from 1-23 seconds.
5	Reverse	OFF (normal)	Terminal 8 is a standard Reverse input.
	Shadow	ON	Terminal 8 is a Shadow reverse input.
6	Overlapping Gates	OFF	Both operators start at the same time.
		ON	Secondary operator starts 1-2 seconds before primary operator.
7	Single	OFF	Switch must be OFF for single operator.
	Dual	ON	Switch must be ON when (dual) operators are used.
8	Spare	OFF	Leave in the OFF position.

Switch 1 Sets direction of the primary operator so that the operator cycles open upon initial power up and open command. If the operator begins to cycle close upon initial power up and open command, turn power off and change the setting on this switch.

Switch 2 Sets direction of the secondary operator so that the operator cycles open upon initial power up and open command. If the operator begins to cycle close upon initial power up and open command, turn power off and change the setting on this switch.

Switch 3 Determines if the output of the loop detector (DoorKing loop detectors only) plugged into the EXIT port will be sent directly to the microprocessor to open the gate, or if the output is directed to Terminal 4 where it can then be connected to other input terminals.

Switch 4 Turns the auto close timer on or off. Maximum time that the close timer can be set for is approximately 23 seconds.

Switch 5 This switch sets the input at Terminal 8 to act as a normal reverse input or to act as a shadow input. A shadow input will only hold the gate operator in the open position once it is in the full open position. A shadow input will not reverse the direction of the gate actuator once it begins its close cycle.

Switch 6 Turns the gate overlap feature on or off. When turned ON, the Secondary operator begins its cycle 1-2 seconds prior to the Primary operator, allowing the Primary gate to reach its full closed position 1-2 seconds before the Secondary gate. This feature is useful when a magnetic lock is used to secure the gates.

Switch 7 Sets up the circuit board for single or dual (Primary / Secondary) gate operation.

Switch 8 Spare switch. Leave in the OFF position.

Continued on next page.

4.2 DIP-Switch Settings Continued

Whenever any programming or switch setting on the control board is changed, press the reset switch for new settings to take effect.

SW 2 (Bottom 4 Switches)			
Switch	Function	Setting	Description
1 and 2	Relay Operation	1-OFF 2-OFF	Relay activates when gate is fully open.
		1-OFF 2-ON	Relay activates when gate is not closed.
		1-ON 2-OFF	Relay activates when gate is opening and open.
		1-ON 2-ON	Relay activates when gate is opening and closing.
3	Maglock	ON	1 second delay to disengage maglock.
	DK Deadbolt Lock	OFF	4-5 seconds delay to retract dead-bolt.
4	Spare	OFF	Leave in the OFF position.

Switch 1 and 2 These work in conjunction with each other and determine when the relay on the board will be activated. This relay can be used as a switch for various functions such as illuminating a warning light when the gate is moving, or turning on a green light when the gate is full open. This relay is not available for these uses if it is being used for the shadow loop function.

Switch 3 Used for a maglock or a DK deadbolt lock.

Switch 4 Spare switch. Leave in OFF position.

4.3 Limit Sensor Adjustments


The limit sensors must be adjusted to precisely set the full open and full closed position of the gate. This feature is especially useful in applications where the gate opens partially, such as on a curved driveway. **Power to the circuit board must be ON when adjusting the limit switches.**

A Manually release operator with key and remove cover with 3 or 4 screws.

B Manually move the gate to the desired open or closed position. Loosen the limit nuts and slowly slide the limit assembly until the **LIMIT LED** on the circuit board lights up.

C Tighten the limit nuts, re-lock operator with key and test the gate stopping positions. Repeat if necessary.


D Re-install the cover. Adjust the secondary operator limit sensors if dual operators have been installed.



4.4 Inherent Entrapment Sensing Adjustment

This vehicular gate operator is equipped with an inherent adjustable reversing sensor (Type A) that is used as the primary entrapment sensing system according to the UL 325 standards. The gate will reverse direction upon encountering an obstruction in either the **opening or closing gate cycle**. For the reverse system to function correctly, the gate must be properly installed and work freely in both directions. A good set of roller bearing hinges is essential for proper swing gate operation.

The ideal adjustment will allow the operator to move the gate through its entire travel cycle without reversing, but will reverse upon contact with an obstruction with no more than 40 Lbs of force. This force can be measured with a gate scale, DoorKing P/N 2600-225. Continued on next page.



The amount of force required for the gate to reverse direction depends on the reverse sensitivity potentiometer.

CAUTION: Keep pedestrians and vehicles clear of the gate while adjusting sensor!


While operator has AC power:




1 Press the Key Switch button to cycle the gate open.

2 While gate is opening, slowly rotate **Primary** reverse sensor clockwise until the **reverse LED lights up** and the gate reverses direction. Rotate reverse sensor back counter-clockwise approximately 1/8 turn.

3 Cycle the gate a few times to be sure that it cycles completely.



Note: Secondary operator must be individually adjusted if dual operators have been installed. Use the **Secondary** reverse sensor.



Test the operators reversing sensitivity:

Place an immobile object along the gate path, allowing the gate to strike it while in the **open** or **close** cycle. The gate must reverse direction after striking the object. If it does not, increase the reverse sensitivity (step **2**) and repeat this test until the correct sensitivity has been set.

4.5 Shutdown Conditions

Under various entrapment conditions the operator will assume either a **SOFT** or **HARD (alarm)** shutdown. To determine what type of reset action is required, you will need to understand how the different entrapment conditions affect the gate operator.

Soft Shutdown

This occurs in various situations where the inherent or secondary entrapment protection devices have been activated. In a soft shutdown condition, the operator **will not** respond to any input that was present when the entrapment protection device sensed or encountered an obstruction. If the gate stops at the open position, the operator **will not** respond to the automatic close timer and a “manual input” is required to close the gate.

- **Example 1** - A time clock keys the gate open in the morning and an entrapment protection device senses an obstruction prior to the gate reaching the full open position. If the entrapment is sensed by the inherent system, the gate will reverse and run back to the closed position. The time clock input is still present, but the gate will not re-open.

Note: In some systems, the time clock input comes from the telephone entry system relay. This same relay may also provide open commands for a card reader, MicroPLUS transmitters and the visitor telephone entry. If so, these devices will also be disabled in a soft shutdown condition.

- **Example 2** - If the gate is closing and an entrapment protection device is activated, the gate will either stop or reverse and run back to the open position, depending upon if the secondary or inherent device was activated. The automatic close timer will not close the gate.
- **Example 3** - If a moving vehicle runs over a loop while the gate is cycling open and hits the opening gate, the operator’s inherent entrapment protection is activated. The gate will reverse direction and run back to the closed position. A soft shutdown condition **does not occur** and the loop provides an immediate reset of the operator. Once the loop area is clear and another open command is given, the gate will cycle open.

Resetting a Soft Shutdown

In some conditions, a soft shutdown will reset as soon as the entrapment condition clears. For example, if a non-contact sensor (photo cell) is sensing an obstruction, the operator will stop the gate and assume a soft shutdown condition. When the photocell clears, the operator will return to normal operation.

When the operator is in a soft shutdown, activation of any “intended input” will reset the operator. An “intended input” includes any command input device, any standard safety input device and any loop input. Activating any of these inputs will reset the gate. At that point the gate will return to normal operation. If the gate is open, the automatic close timer will then time out and close the gate.

4.5 Shutdown Conditions Continued

Hard Shutdown

A hard shutdown condition occurs when the inherent entrapment protection system has sensed two consecutive obstructions before the gate reaches the full open or closed position.

- **Example** - The gate is closing and the inherent entrapment protection system senses an obstruction and causes the gate to reverse direction. As the gate begins to run in the open direction, a second obstruction is sensed prior to the gate reaching the full open position. Once the second obstruction has been sensed, the operator will stop, the audio alarm will be activated and **ALL** standard inputs are shut down (including open commands, safety commands, loop inputs, etc.).

Note: The audio alarm will remain activated for a maximum of five minutes, or until the operator receives a reset input. **The hard shutdown condition will remain in affect even if the audio alarm shuts off after five minutes.**


- After 5 minutes, the audio alarm will “chirp” every 5 seconds. This indicates that the operator is in a hard shutdown condition and the **Reset Button** or the **Alarm Reset Button** must be activated to reset the operator and silence the alarm. See illustration below.

Resetting a Hard Shutdown

When the operator is in a hard shutdown condition (audio alarm activated or audio alarm “chirps” every 5 seconds), to reset the gate operator and return it to normal operation, activate the **Reset Button** or the **Alarm Reset Button**.

- Before resetting a hard shutdown, determine why the shutdown occurred. Inspect the gate for any obstructions along its path that could have activated the inherent entrapment sensing system. Inspect the gate and gate hardware.

Note: DoorKing operators have a built-in alarm reset push buttons on the circuit board and on the bottom of the control box for quick access. Activating either one of these buttons will return the gate operator to normal operation, but will not activate the gate operator.



Once the gate has been reset, an open or close command is needed to start the gate operator. Most activating commands will cause the gate operator to cycle to the open position. This includes activation of a key switch or open command and activation of an open loop. Activation of a close command will run the gate to the closed position.

SECTION 5 - MAINTENANCE AND TROUBLESHOOTING

Inspection and service of this gate operator by a qualified technician should be performed anytime a malfunction is observed or suspected. High cycle usage may require more frequent service checks.

5.1 Maintenance

When servicing the gate operator, always check any secondary (external) reversing devices (loops, photo cells, etc.) for proper operation. If external reversing devices cannot be made operable, do not place this operator in service until the malfunction can be identified and corrected.

Always check the inherent reversing system when performing any maintenance. If the inherent reversing system cannot be made operable, remove this operator from service until the cause of the malfunction is identified and corrected. Keeping this operator in service when the inherent reversing system is malfunctioning creates a hazard for persons which can result in serious injury or death should they become entrapped in the gate.

When servicing the gate operator, be sure that the 24 VAC input power and batteries are disconnected.

Operator Component	Maintenance	Monthly Interval		
		3	6	12
Alarm	Activate the primary (inherent) reverse system by blocking the gate with a solid object. When the gate reverses, block the gate in the opposite direction prior to the limit being reached. The entrapment alarm should activate. Press the reset button to silence the alarm.	✓		
Batteries	Check the batteries for any leakage or loose connections. Batteries should be replaced every two years.	✓		
Fire Dept.	Check emergency vehicle access device for proper operation.	✓		
Gate	Inspect for damage. Check gate hinges for wear and grease if necessary.		✓	
Primary Reverse System	Check that the gate reverses on contact with an object in both the opening and closing cycles. Adjust the reversing sensor if necessary.	✓		
Loop(s)	Check vehicular reverse and shadow loops for proper operation.	✓		
Release	Check manual release for proper operation.	✓		
Secondary Reverse Device	Check secondary (external) reverse device(s) stop or reverse the gate when activated.	✓		
Complete System	Complete check of gate and gate operating system.			✓

5.2 Diagnostics Check

Have the following diagnostic tools available: VOM meter with minimum voltage memory or min-max range to check voltage and continuity. Meg-ohm meter capable of checking up to 500 megohms of resistance to properly check ground loop integrity. A malfunction can be isolated to one of the following:

- Gate Operator
- Loop System
- Keying Devices.

Disconnect all external inputs to the circuit board.

1. Check the input indicator LED's. They should only come ON when a keying device (card reader, push button, etc.) is activated. If any of the input LED's are ON continuously, this will cause the gate operator to hold open. Disconnect the keying devices one at a time until the LED goes OFF (see troubleshooting guide).
2. If the operator stops or holds open, check external secondary entrapment protection devices for any shorts or malfunction.
3. A malfunction in a loop or loop detector can cause the gate operator to hold open, or not detect a vehicle when it is present over the loop. Pull the loop detector circuit boards from the loop ports on the operator circuit board. If the malfunction persists, the problem is not with the loop system. For more information refer to the loop detector instruction sheet and the DoorKing Loop and Loop Detector Information Manual. Continued on next page.

5.2 Diagnostics Check Continued

4. Check that there are no shorted or open control wires from the keying devices to the gate operator. If a keying device fails to open the gate, momentarily jumper across terminals 1 and 2 on the control board. If the gate operator starts, this indicates that a problem exist with the keying device and not with the gate operator.

5. Check the supply voltage and batteries. A voltage drop on the supply line (usually caused by using too small supply voltage wires) will cause the operator to malfunction. Batteries should be fully charged for proper operation, replace batteries every two years on average.

5.3 Troubleshooting

Symptom	Possible Solution(s)
Operator(s) will not run. Power LED is OFF.	<ul style="list-style-type: none"> • Check that AC power to the operator is turned ON. • Check battery power. • Check for 24 VAC at terminals 19 and 20. If voltage measures OK, check the terminal strip or replace the circuit board.
Operator(s) will not run. Power LED is ON.	<ul style="list-style-type: none"> • Momentarily jumper terminal 1 to terminal 2. If the input LED does not come ON, check the terminal strip or replace the circuit board. If LED does come ON, proceed to next steps. • Check the fuses. • Check Motor(s): Remove the circuit board. With two 14 AWG insulated jumper wires, momentarily jumper the battery terminals to the motor terminals (1, 2) of the Primary operator connector. The operator should run. Swap the two wires at the terminal strip. The operator should run in the opposite direction. Repeat these steps using the Secondary operator connector. • If the operator(s) run in both directions in the step above, replace the control board. If the operator(s) do not run, or run in only one direction, problem can be a bad operator, wire connections from the control board to the operator(s) or a bad control board.
Gate opens a short distance, then stops and reverses.	<ul style="list-style-type: none"> • Check the reversing sensitivity. • Check the secondary safety devices. • Disconnect the gate from the gate operator and check that the gate swings freely without any binding. • Replace the circuit board.
Gate opens but will not close.	<ul style="list-style-type: none"> • Check the input LEDs. Any ON will hold the gate open and indicates a problem with a keying device. • Check the secondary safety devices. Any activated will hold the gate open and indicates a problem with the safety device. • Check the loop detectors. Any activated can hold the gate open and indicates a problem with the loop detector or ground loop. • Operator may be in a “soft shutdown.” Activate any keying device to determine if operator returns to normal operation. • If automatic close is desired, be sure SW 1, switch 4 is ON.
Gate closes but will not open.	<ul style="list-style-type: none"> • Operator may be in a “soft shutdown.” Check input LEDs. If any are ON, momentarily disconnect, then re-connect the wire going to the respective terminal. Operator should open. • Check to be sure that the operator is running in the proper direction. Turn power OFF, and then back ON. Activate a keying device. Operator should run in the open direction. If operator runs in the close direction, turn power OFF and change direction switch SW 1, switches 1 and/or 2. Go to above section if operator now opens but will not close. • Be sure that the respective LED on the control board lights when the keying device connected to the respective terminal is activated. If LED does not light, momentarily place a jumper wire from terminal 1 to the input terminal being checked. If LED lights and gate opens, problem is with the keying device. If LED does not light, replace control board. • Check motor as described above “Operator(s) will not run. Power LED is ON”.

5.3 Troubleshooting Continued

Symptom	Possible Solution(s)
Gate starts to close, then reverses to open.	<ul style="list-style-type: none"> • Disconnect the gate from the operator and check that the gate operates freely without any binding. • Check the loop detector LED's and input LED's. Any that flash ON will cause the gate to reverse. • If a shadow loop is used, check for proper wiring. A mis-wired shadow loop detector will cause the gate to reverse. • Replace the circuit board.
Gate closes and opens continuously.	<ul style="list-style-type: none"> • Check for any input or loop detector LED's that are ON. • Check that the operator is running in the proper direction (see "gate closes but will not open"). • Check the SELF TEST jumper, see page 30.
Alarm sounds for 5 minutes and then beeps once every 5 seconds. Operator will not run.	<ul style="list-style-type: none"> • Operator is in a "hard shutdown" condition. Reset switch must be activated to return operator to normal operation, see Hard Shutdown Section 4.5, page 34.

5.4 Accessory Items

The following accessory items are available for the models 6002, 6003 and 6400 swing gate operators.

Photo Cell - Non-contact (photo-cells) sensors for use as a secondary entrapment protection device.

EMX Industries, Inc. Model IRB-325

MMTC, Inc. Model E3K-R10K4-NR

Loop Detector - Detectors plug directly into ports on circuit board simplifying wiring.

P/N 9410-010 - Single channel detector

P/N 9409-010 - Two-channel detector

Magnetic Lock - Magnetic Gate Lock Kit provides an excellent means to secure swing gates and is a fail-safe device allowing emergency vehicle access upon power outage.

P/N 1216-080 and P/N 1216-081

Interconnect Cable - Interconnect wire cable contains all the necessary wires to interconnect primary / secondary operators.

Cable length 30 feet. P/N 2600-755 Cable length 40 feet. P/N 2600-756 Cable length 50 feet. P/N 2600-757

Time Clock - 7 day and 365 day time clocks can be used to automatically open gate at pre-set time and days. Compact clock fits inside the control box.

P/N 2600-791 - 7 day clock

P/N 2600-795 - 365 day clock

Hinges - Heavy-duty ball bearing hinges provide easy swing gate operation.

P/N 1200-009 (Flange) , P/N 1200-019, P/N 1200-039. Two (2) required.

Surge Devices - High and low voltage surge suppressors help prevent circuit board failure caused by lightning strikes and power surges.

P/N 1876-010 - High Voltage

P/N 1878-010 - Low Voltage

Gate Scale - Use to test torque required to move gate. P/N 2600-225


Speed Bumps - Prefabricated six-foot speed bump reduces traffic speed through gate system. P/N 1610-150

Batteries - 12 Volt 3 Amp Hour. P/N 1801-009. Two (2) required.

Control Box, Deluxe or Standard


Secondary Operator Connector

Primary Operator Connector




12 V
3 Amp/Hr
Battery

12 V
3 Amp/Hr
Battery




Deluxe Control Box

Convenience Outlets 115 VAC




Transformer




Standard Control Box

AC Power




Transformer




Alarm
Reset
Button

Models 6002 , 6003 and 6400


6002



6003



6400



Owner's Manual

Standard or Deluxe Control Box for: 6002 * 6003 * 6400
Vehicular Swing Gate Operators



DoorKing, Inc.
120 Glasgow Avenue
Inglewood, California 90301
U.S.A.

Phone: 310-645-0023
Fax: 310-641-1586